

OVERVIEW

Access Doors are designed and built for years of convenient and easy access to mechanical areas in commercial buildings.

The following is a general instruction for installing Concealed Drop-In Access Doors. These are recommended general guidelines only. Locally accepted practices and procedures should be followed to ensure the ultimate durability of access door installed in different types of construction.

INSTALLATION

1. Frame opening.



2. Mount flange (seamless surround) with drywall screws.



3. Place door in opening.



4. Install drywall.



5. Tape and apply drywall compound.



6. Apply desired finish.