



VINYL END WALL GUARD

Model(s): BCGV-EW-P

GENERAL DESCRIPTION



Introduction + Safety

Nystrom's Vinyl End Wall Guards are an attractive and durable solution to unsightly, damaged corners. Backed by a limited five-year warranty, Nystrom's Corner Guards are available in 70 colors, is Class A fire-rated and meet national building code standards.

Please read the complete instructions carefully before beginning any work. To ensure proper installation and performance of the product, the following actions must be completed by the installing contractor. Failure to do so will affect product warranty.

GENERAL SAFETY PRECAUTIONS Improper selection, installation, or use can cause personal injury or property damage. It is solely the responsibility of the user, through its own analysis to select products suitable for their specific application requirements, ensure they are properly maintained, and limit their use to its intended purpose. Follow proper local, state and federal regulations for proper installation and operation requirements.

Transportation + Storage

- o Inspect all shipments and materials for missing or damaged components and hardware.
- Material must be stored in a clean, dry location.

INSTALLATION

- 1. Locate and install Surface Adhered Extruded Vinyl Corner Guard in accordance with architectural drawings and specifications.
- 2. Lay out work to be completed at the base of the substrate. Check the material for any damage that may have occurred during shipment and/or handling at job site.



- 3. Prior to installation, allow Corner Guards to reach room temperature. Inspect wall corners to confirm sound construction and repair if necessary. Thoroughly clean wall surfaces to assure proper Corner Guard adhesion.
 - a. CAUTION: Other cleaning agents may damage certain types of wall finishes. Use the appropriate manufacturer-recommended cleaning agent and proceed with care.
- 4. If the wall surface is unusual in composition and/or texture or exhibits other characteristics that may jeopardize the effectiveness of the installation method, please contact your local Nystrom rep.
- 5. Dry-fit the Corner Guard to the wall corner to assure proper height and fit.
- 6. Surface Adhered Corner Guards are provided in specified heights with or without factory-applied adhesive backing. If no adhesive has been provided, use only contact adhesive, Locite® PL® 200 Construction Adhesive, or Liquid Nails® Tub Surrounds & Shower Walls Adhesive and follow manufacturer's recommended procedures.
- 7. If adhesive-backed Corner Guards have been provided, carefully peel back and thoroughly remove the release liner from back of Corner Guard. Do not allow exposed adhesive to contact substances that will adhere and contaminate the adhesive surface.
- 8. Holding the Surface Adhered Corner Guard at an angle, carefully place and seat its bottom end against the corner at the proper location. Using care fit the Corner Guard to the corner, progressing from bottom to top, applying pressure with fingers and palm to assure that it is seated precisely on the corner. If Corner Guards are full height, it is best that two people perform this operation.
- 9. After placement, inspect the Corner Guard from top to bottom to confirm proper fit and surface contact. Using a high-pressure roller, firmly and thoroughly roll both wings of the Corner Guard to assure full and complete adhesion.

OPERATION

Vinyl Corner Guards are designed for years of wall protection. Perform annual inspections to ensure proper fitment and performance.

MAINTENANCE

1. Use mild detergent to clean soiled surfaces. Pen marks, paint and graffiti generally wash off easily with mild soap and water. Completely rinse the surface with clean water when complete.



- Note: Powdered cleansers and bleach cleaners should be used with care as they may leave a residue embedded in the cover surface. Properly rinsing with clean water will remove any residual residue.
- 2. Tough marks or stains may require a heavy-duty cleaner such as "Crown Anti-Vandal Spray" or "DWR-II". These specialized spot cleaners should only be used on small areas and tested for color fastness prior to applying in a highly visible area. Rinse thoroughly with clean water to remove the residue from these cleaners.

QUESTIONS?

For more information on installation, repair or replacement, please visit www.Babcockdavis.com or call (888)412-3726

